

UC3430

CAMLIVE PRO 4K 4-Input HDMI to USB Video Switcher User Manual

Compliance Statements

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital service, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.



KCC Statement

유선 제품용 / B 급 기기 (가정용 방송 통신 기기) 이 기기는 가정용 (B 급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며,모든 지역에서 사용할 수 있습니다.

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

CAN ICES-003 (B) / NMB-003 (B)

HDMI Trademark Statement

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



RoHS

This product is RoHS compliant.



User Information

Online Registration

Be sure to register your product at our online support center:

International	http://eservice.aten.com

Telephone Support

For telephone support, call this number:

International	886-2-8692-6959
China	86-400-810-0-810
Japan	81-3-5615-5811
Korea	82-2-467-6789
North America	1-888-999-ATEN ext 4988 1-949-428-1111

User Notice

All information, documentation, and specifications contained in this manual are subject to change without prior notification by the manufacturer. The manufacturer makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties as to merchantability or fitness for any particular purpose. Any of the manufacturer's software described in this manual is sold or licensed *as is*. Should the programs prove defective following their purchase, the buyer (and not the manufacturer, its distributor, or its dealer), assumes the entire cost of all necessary servicing, repair and any incidental or consequential damages resulting from any defect in the software.

The manufacturer of this system is not responsible for any radio and/or TV interference caused by unauthorized modifications to this device. It is the responsibility of the user to correct such interference.

The manufacturer is not responsible for any damage incurred in the operation of this system if the correct operational voltage setting was not selected prior to operation. PLEASE VERIFY THAT THE VOLTAGE SETTING IS CORRECT BEFORE USE.

Product Information

For information about all ATEN products and how they can help you connect without limits, visit ATEN on the Web or contact an ATEN Authorized Reseller. Visit ATEN on the Web for a list of locations and telephone numbers:

International	http://www.aten.com
North America	http://www.aten-usa.com

Package Contents

Check to make sure that all the components are in working order. If you encounter any problem, please contact your dealer.

- 1 UC3430 CAMLIVE PRO 4K 4-Input HDMI to USB Video Switcher
- 1 USB-C to USB-C cable
- 1 USB Type-A to USB-C cable
- 1 power adapter and power cord
- 1 user instructions

Table of Contents

	Compliance Statements User Information Online Registration Telephone Support User Notice Product Information Package Contents Table of Contents V About this Manual Conventions	
1.	Introduction Overview Features Planning the Installation Requirements Supported Operating System and Requirements Components	2 3 3 3
2.	Hardware Setup Connecting the CAMLIVE PRO 4K Unit.	9
3.	Livestream / Record Setup Livestream / Record Platform	1 1 4
4.	ATEN OnAir Lite App ATEN OnAir Lite Application 2' Supported Systems 2' Installing the ATEN OnAir Lite App 2' Page Components 2' Project Settings 2' Device Settings 2' Help 2' System Information 2' Video Mixer 2' Resize 2'	113445567

Crop	
Overlay Button	
Reset Scene Button	
Audio Mixer	
Settings Panel	
General	
Chroma Key	

Appendix

Safety Instructions
General
Technical Support
International
North America
Specifications
ATEN Standard Warranty Policy44

About this Manual

This user manual is provided to help you get the most out of your CAMLIVE PRO 4K unit. It covers all aspects of the device, including installation,

configuration, and operation.

The model covered in this manual is:

Model	Product Name	
UC3430	CAMLIVE™ PRO 4K 4-Input HDMI to USB Video Switcher	

An overview of the information found in the manual is provided below.

Chapter 1, Introduction, introduces you to the CAMLIVE PRO 4K, its purpose, features, installation considerations, with its panel components described.

Chapter 2, Hardware Setup, describes the steps that are necessary to quickly and safely set up your CAMLIVE PRO 4K.

Chapter 3, Livestream / Record Setup, explains how to find CAMLIVE on your system and guides you to set up video and audio sources using an example (live-stream / record software / platform).

Chapter 4, ATEN OnAir Lite App explains how to download and configure the CAMLIVE PRO 4K's OnAir Lite app.

Appendix, provides a list of safety instructions and precautions, and other product specifications and technical information of the product.

Note:

- Read this manual thoroughly and follow the installation and operation procedures carefully to prevent any damage to the unit or any connected devices.
- The product may be updated, with features and functions added, improved or removed since the release of this manual. For an up-to-date user manual, visit <u>http://www.aten.com/global/en/</u>

Conventions

This manual uses the following conventions:

Monospaced Indicates text that you should key in.

- Indicates keys you should press. For example, [Enter] means to press the Enter key. If keys need to be chorded, they appear together in the same bracket with a plus sign between them: [Ctrl+Alt].
- 1. Numbered lists represent procedures with sequential steps.
- Bullet lists provide information, but do not involve sequential steps.
- Indicates selecting consecutive options (such as on a menu or dialog box). For example, Start > Run means to open the *Start* menu, and then select *Run*.



Indicates critical information.

Chapter 1 Introduction

Overview

The CAMLIVE PRO 4K (UC3430) 4-Input HDMI to USB Video Switcher captures up to four 4K @ 60 HDM inputs, enabling users to mix dual video signals into one single stream while supporting multiple output options, including 4K @ 60 HDMI PGM / Loop-through for multiview screen purposes and 4K @ 30 USB-C output for live broadcast on the Internet. The USB-C output supports popular streaming software including Zoom, Microsoft Teams, Youtube, Facebook, GoToWebinar, Open Broadcaster, XSplit Broadcaster, and Twitch on Windows and Mac. Plus, the CAMLIVE PRO 4K features audio mixer functionalities to mix up to 4 HDMI audios and 1 line-level audio for users to add live narration / music to the content, boosting the production value of your creation.

When working with the intuitive ATEN OnAir Lite app, users can remotely control device settings in real-time, from multiple AV source switching / mixing, content cropping / resizing, layout to transitions. Apart from the versatile transition effects, the PiP / PbP / PoP functions and the support for Chroma Key help users create a dynamic presentation that will never bore the audience. In order to amplify brand identity, users are allowed to add logos in PNG / BMP / JPG format to the content. Apart from the app, the CAMLIVE PRO 4K is also controllable through its front panel pushbuttons and RJ-45 port for serial control via ATEN VK Control System.

The CAMLIVE PRO 4K works with a rack mount kit (sold separately) to give installation flexibility in media cabinets or DIT stations. With the switcher's one-stop programming and streaming functionalities that work on Windows / Mac platforms, multi-camera streaming in scenarios in need of sharp, vivid UHD quality such as multi-cam studios, corporate conferences, lecture halls, houses of worship, and live events, has never been so easy.

Features

- Captures 4 channels of 4K @ 60 HDMI, mixes and switches the streams while providing audio mixer functionalities and seamless transition for pro-level broadcasting
- Multiple output options:
- HDMI PGM / Loop-through at 4K @ 60 for multiview screen purposes
- USB-C output 4K @ 30 for live broadcast on the Internet
- Built-in audio mixer mixes up to 4 HDMI audios and 1 line-level audio for adding live narration / music to the content
- Versatile control methods via the front panel pushbuttons, RJ-45 port for serial control via ATEN VK Control System, and ATEN OnAir Lite app
- ATEN OnAir Lite app users can remotely control device settings in real-time, including multiple AV source switching / mixing, content cropping / resizing, layout options (full screen / PiP / PbP / PoP), transitions, Chroma Key, and logo adding
- Compatible with popular streaming software including Zoom, Microsoft Teams, Youtube, Facebook, GoToWebinar, Open Broadcaster, XSplit Broadcaster, and Twitch
- Supports UVC / UAC v1.1
- Plug-and-Play functionality with USB-C 3.2 Gen 1 compliance
- Works with major operating systems: Windows[®] and Mac OS X[®]

Planning the Installation

Requirements


Prepare the following before installing the CAMLIVE PRO 4K unit:

- 4 HDMI source devices
- 2 HDMI displays
- 1 hardware / software controller
- 1 audio input source
- 1 audio output source
- 1 USB-C enabled computer


Supported Operating System and Requirements

Operating System	Minimum Hardware Requirement	
Windows 10 or above	CPU: Intel® i3 Dual Core 2.8Ghz or higher	
	RAM: 4GB or more	
	One USB-C Interface or USB-A Interface	

Components



Rear View



No.	Component	Description	
1	port selection pushbuttons	Press a port selection pushbutton to bring the video and audio focus to the HDMI source attached to its corresponding port.	
2	on air pushbutton (USB video on / off control)	Press to broadcast the selected HDMI source.	
3	layout selection pushbutton	Press to select a layout option between full screen, PiP (Picture in Picture), and PbP (Picture by Picture).	
4	HDMI loop out pushbutton	Press to bring the selected HDMI source to the HDMI- enabled monitor connected to the HDMI loop out port.	
5	grounding terminal	The grounding wire used to ground the switch attaches here.	
6	power switch	Switches the unit's power on and off.	

No.	Component	Description	
7	power jack	The power adapter plugs here.	
8	RJ-11 port	Not applicable for now, reserved for future expansion.	
9	RJ-45 port (RS-232 control)	Connects to a control system (e.g., VK Control Box) via Cat 5 cable for control purposes. For more information, please see VK Control Box's user manual.	
10	line input port	Connects to an audio input device, e.g., audio mixer.	
11	line output port	Connects to an audio output device, e.g., audio amplifier.	
12	HDMI input ports	Connect up to four HDMI input sources.	
13	HDMI output port (PGM)	Connects to an HDMI-enabled display for programmed (PGM) video output.	
14	HDMI output port (loop out)	Connects to an HDMI-enabled display for HDMI loop out video output.	
15	USB-C port	Connects to a host.	

This Page Intentionally Left Blank


Chapter 2 Hardware Setup



Please review the safety information regarding the placement of this device in *Safety Instructions*, page 39.

Connecting the CAMLIVE PRO 4K Unit

Follow the steps below to connect the CAMLIVE PRO 4K.



- 1. Ground the unit.
- 2. Connect up to 4 HDMI sources to the unit's HDMI input ports.
- 3. Connect an HDMI-enabled display to the unit's HDMI output port (PGM).
- 4. Connect an HDMI-enabled display to the unit's HDMI output port (loop out).

- 5. Connect a USB-C computer to the unit's USB-C port for OnAir Lite app / live stream use.
- 6. Connect an audio mixer to the unit's audio input port.
- 7. Connect an audio amplifier to the unit's audio output port.
- 8. Connect a control system (e.g., VK Control Box) to the unit's RJ-45 port via Cat 5 cable for control purposes.
- 9. Connect the power adapter to the unit's power jack.
- 10. Switch the power on.

Software

To enable CAMLIVE PRO 4K, please download and install a suitable video recording or live streaming software for your requirement.

<u>PC</u>

Below lists some examples of supported video recording / live streaming software for PC.

All trademarks are property of their respective owners.

OBS: https://obsproject.com

Xsplit: https://www.xsplit.com

https://www.youtube.com

https://www.facebook.com

https://www.zoom.com

https://www.skype.com

https://www.microsoft.com/en-us/microsoft-365

This Page Intentionally Left Blank

Chapter 3 Livestream / Record Setup

Livestream / Record Platform

Below lists a few of the available live-streaming or recording software/ platforms:

OBS: https://obsproject.com

Xsplit: https://www.xsplit.com

https://www.youtube.com

https://www.facebook.com

https://www.zoom.com

https://www.skype.com

https://www.microsoft.com/en-us/microsoft-365

All trademarks are property of their respective owners.

Discovering CAMLIVE on your System

CAMLIVE PRO 4K is a plug-and-play device, please make sure your system is able to discover it. After connecting CAMLIVE PRO 4K as shown in *Connecting the CAMLIVE PRO 4K Unit* on page 7, refer to the examples below on how your system may discover CAMLIVE PRO 4K.

Windows Operating System

This is an example used in a Windows 10 Operating System.

1. On a Windows 10 desktop, go to Control Panel and select System.

All Control Panel Items		- 0	I X		
$\leftrightarrow \rightarrow \checkmark \uparrow \square \rightarrow \text{Control Panel} \rightarrow \text{All Control Panel Items} \checkmark [0] $					P
Adjust your computer's settings				View by: Small icons 🔻	
繼 Administrative Tools	Adobe Version Cue CS3 (32-bit)	AutoPlay	🐌 Backup and Restore (Windo	ws 7)	
Note: Prive Encryption	💶 Color Management	Credential Manager	鹶 Date and Time		
C Default Programs	📇 Device Manager	R Devices and Printers	Ease of Access Center		
File Explorer Options	le History	Flash Player (32-bit)	A Fonts		
• 4 HomeGroup	🔒 Indexing Options	🖉 Infrared	👹 Intel® Graphics Settings		
😒 Internet Options	🔿 Java (32-bit)	Keyboard	🛠 Language		
Mouse	🛂 Network and Sharing Center	📰 Phone and Modem	Power Options		
Programs and Features	😂 Realtek HD Audio Manager	🐼 Recovery	🔗 Region		
🐻 RemoteApp and Desktop Connections	🎢 SAP GUI Configuration (32-bit)	r Security and Maintenance	Sound		
Speech Recognition	Storage Spaces	🔇 Sync Center	🔛 System		
Taskbar and Navigation	Troubleshooting	🍇 User Accounts	Windows Defender Firewall		
늘 Windows To Go	Work Folders	🥥 郵件 (32-bit)			


2. The System window appears, select Device Manager.

🔛 System			- 🗆 ×
🗧 🔶 👻 🛧 🔛 > Control P	anel > All Control Panel Items >	System	v ひ Search Control Panel タ
Control Panel Home	View basic information	about your computer	6
💡 Device Manager	Windows edition		
Remote settings	Windows 10 Pro		
System protection	© 2017 Microsoft Corporat	tion. All rights reserved.	Windows 10
😔 Advanced system settings			
	System		
	Manufacturer:	Acer	
	Model:	Veriton M2640G	
	Processor:	Intel(R) Core(TM) i5-7500 CPU @ 3.40GHz 3.41 GHz	arer
	Installed memory (RAM):	16.0 GB	
	System type:	64-bit Operating System, x64-based processor	
	Pen and Touch:	No Pen or Touch Input is available for this Display	
	Acer support		
	Website:	Online support	
	Computer name, domain, and	workgroup settings	
	Computer name:	8060P-lanS2	Change settings
	Full computer name:	8060P-lanS2.aten.com	
	Computer description:		
	Domain:	aten.com	
	Windows activation		
See also	Windows is activated Rea	d the Microsoft Software License Terms	
Security and Maintenance	Product ID: 00330-51889-8	4255-AAOEM	Change product key

3. The Device Manager window appears. Click on **Cameras** and **Sound**, video and game controllers.

File Action View Help Image: Source of the state of	🛃 Device Manager	-	Х
▼ BooDP-IanS2 > Computer > Computer > Disk drives > Primware > Muman Interface Devices > Mice and other pointing devices > Monitors > Network adapters > Print queues > Print queues > Software devices > Software devices > Software controllers > System devices	File Action View Help		
 Audio inputs and outputs Cameras Computer Disk drives Disk drives Display adapters Firmware Firmware Firmware Firmware Monitors Keyboards Monitors Network adapters Network adapters Print queues Print queues Software devices System devices 			
> @ Cameras > @ Disk drives > @ Disk drives > @ Display adapters > @ Firmware > @ Human Interface Devices > @ Revolution Interface Devices > @ Mice and other pointing devices > @ Monitors > @ Network adapters > @ Network adapters > @ Ports (COM & LPT) > @ Print queues > @ Socurity devices > @ Sotware devices > @ Sotware devices > @ Sotware devices > @ Sotware devices > @ System devices	✓		
 Computer Disk drives Display adapters Display adapters Timware Human Interface Devices Keyboards Keyboards Mice and other pointing devices Monitors Wetwork adapters Ports (COM & LPT) Ports (COM & LPT) Processors Software devices Software devices Software devices System devices System devices 	> II Audio inputs and outputs		
 Disk drives Disk drives Disk drives Firmware Human Interface Devices Human Interface Devices De ATA/ATAPI controllers Keyboards Monitors Monitors Network adapters Network adapters Print queues Print queues Processors Software devices Software devices Sound, video and game controllers System devices System devices 	> 💿 Cameras		
 Display adapters Firmware Human Interface Devices Keyboards Keyboards Mice and other pointing devices Monitors Network adapters Ports (COM & LPT) Print queues Processors Software devices Software devices Sotware devices System devices System devices 	> 💻 Computer		
 Firmware Firmware Firmware Firmware Firmware IDE ATA/ATAPI controllers Keyboards Monitors Monitors Potts (COM & LPT) Ports (COM & LPT) Print queues Print queues Software devices Software devices Software devices Software devices System devices System devices 	> 👝 Disk drives		
 Reference devices Human Interface Devices DE ATA/ATAPI controllers Keyboards Monitors Monitors Network adapters Print queues Print queues Processors Software devices Software devices Software devices Software devices System devices System devices 	> 🖳 Display adapters		
 DE ATA/ATAPI controllers Keyboards Mice and other pointing devices Monitors Network adapters Ports (COM & LPT) Print queues Processors Software devices Software devices Software devices Software controllers System devices 	> 📓 Firmware		
 Keyboards Mice and other pointing devices Monitors Wetwork adapters Ports (COM & LPT) Print queues Processors Processors Software devices Software devices Software devices System devices System devices 	> 🛺 Human Interface Devices		
> ● Mice and other pointing devices > ● Monitors > ● Network adapters > ● Ports (COM & LPT) > ● Print queues > ● Processors > ● Software devices > ● Software devices > ● Software controllers > ● System devices	> 📹 IDE ATA/ATAPI controllers		
> Monitors > Network adapters > Ports (COM & LPT) > Print queues > Processors > Software devices > Software devices > Software devices > Software controllers > System devices > System devices			
 Retwork adapters Ports (COM & LPT) Print queues Processors Security devices Software devices Software devices Sound, video and game controllers System devices 	> 🕕 Mice and other pointing devices		
 > Ports (COM & LPT) > □ Print queues > □ Processors > □ Software devices > □ Software devices > □ Software devices > □ Sotrage controllers > □ System devices 			
> Image: Print queues > Image: Processors > Image: Software devices > Image: Software devices > Image: Image: Image: Software devices > Image: Im			
> ■ Processors > ■ Security devices > ■ Software devices > ■ Software devices > ■ Storage controllers > ■ System devices			
> ■ Security devices > ■ Software devices > ■ Software devices > ■ Storage controllers > ■ System devices			
> I Software devices > I Sound, video and game controllers > I System devices			
Sound, video and game controllers Say Storage controllers The second seco			
> 🥁 Storage controllers > 🏣 System devices			
> 🏣 System devices			
> 🌵 Universal Serial Bus controllers			
	> 🏺 Universal Serial Bus controllers		

4. You should see an "USB Video Device" in the *Camera list*, and an "USB Audio Device" in the *Sound*, *video and game controllers list*. This indicates that your system has successfully discovered CAMLIVE PRO 4K.



Video and Audio Setup


After your system discovers CAMLIVE PRO 4K, choose your livestream/ record platform. You will need to setup the video and audio source coming from CAMLIVE PRO 4K.

Follow the steps below to setup your video and audio sources (separately).

Note: OBS software is the example used in the setup steps below.




1. On your system, open the OBS software.



2. Locate and click the "+" button on the bottom of the "Sources" pane (outlined in red in the picture below) to open the add source menu:

4	000	C71 -	F - F +	3 P	0	0	W	11-la			•		- +				- 5-04 014	0	•
	OBS	File	Edit	View	Profile	Scene Collection	Tools	Help	000 01-12-0111	odified (mac) - Profile: U	 9 6	n r¥1	÷. •	i) 100% (gg		Mo	on 5:21 PM	Q	Q :=
		_	_	_	_		_	_	000 01000 21111 11		_	_	_	_	_	-	_	_	_
										Transition									
										Quick Transitions +									
										quick mananona									
		Scen	es							Mixer			Sce	ne Transitio				Control	
Scene												Fad							
												Durat	ion 300	ims		۵		idio Mi	
																		Setting	
						- • ^ ~													
+ -					+	- • ~ ~													
												LIVE: 0	0:00:00	REC: 0	0:00:0		CPU: 2.2%, 2	1.29 f	

3. Select "Video Capture Device" or "Audio Capture Device.




4. A pop-up window will be shown for you to name the video/audio source. Click the "OK" button to continue.

It is recommended that "Make source visible" is checked.

. Ś	OBS	File	Edit	View	Profile	Scene Collection	Tools	Help		🖻 🐵 🖵 🛜 🜒	100% 252	А	Mon 5:21 PM	९ 🔕 😑
									Create new Control Control Marke source viable Cancel Oc					
		Scen	o r		_	Sources		_	Mixer	Scana	Transitions			Controls
Scen	e 1	ocer				Sources			Mixer	Fade	THERE			t Streaming
acc.										1.906		- 1		t Streaming t Recording
										Duration 300m				adio Mode
										Duration Scott	, ,			
Γ														Settings
Γ.														
+					+	- • ^ ~								
										LIVE: 00:00:00	REC: 00:0	00:00		15.94 fps
	ا 🙄	5		Ø		1 🖪 🚺	1		al 👝 🎫 🖸 🚏 🕖 💭 PT 🥵 🕲	E 📥 💋 🕻) 🔚	6		- Ť

5. On the properties page, click the drop-down menu named "Device" to select CAMLIVE PRO 4K's video/audio source. Both the video and audio sources of CAMLIVE PRO 4K have the name "HDMI to U3 capture".



After selecting the video source, the image from CAMLIVE PRO 4K should be displayed as shown below.

Click the "OK" button to continue.



6. For successful setup, the sources will be shown in the "Source" panel.

SOBS File Edit View Pr	rofile Scene Collection Tools Help		🚱 💿 🔽 奈 🜒 100% 👧 🛃	Mon 5:23 PM Q 🥥 😑
• • •		OBS Studio 21.1.1-modified (mac) - Profile: Untitled - Scenes: QSG		
8 HS 4 8 5 1	Fi O 1	IHD • 1 : 4 7 : 1 5 • 0 id * 7amilion ● • 0 id * 7amilions ■		
Scenes	Sources	Mixer	Scene Transitions	Controls
Scene 1	👁 🗎 Audio Input Capture			
			Duration 300ms	C Studio Mode
+ - ^ ~	+ - • ^ ~			
			LIVE: 00:00:00 REC: 00:00:00	O CPU: 7.3%, 30.00 fps
🖉 💟 🕵 🔕 💟	5 🗂 📕 🗂 🗉 🏵	🛓 🕤 🏹 🝸 🗊 💭 🖭 🤔 🔯 I	🔳 🖕 💋 🔿 🖿 🔇) 💷 🐂 🖱 🐇

Setup of video and audio sources are complete, you can now start live-streaming/video recording.

Detailed configuration of your live-streaming/video recording software/ platform is not within the scope of this user manual, please refer to the software/platform's instruction guides/manual.

Using the USB Cables

When connecting CAMLIVE PRO 4K on a PC with a USB 2.0 interface, it will automatically set the provided compressed video quality to the MJPEG compression mode to fit the data bandwidth. For better video quality, we strongly recommend to connect CAMLIVETM PRO to a USB 3.1 Gen1 interface.

To make sure the result match your media output you wish to capture, please check the detected video format from your capture software first.

Capture device custom setting page examples displaying USB 3.1-RAW and USB 2.0-MJPEG on OBS software are shown below:

• USB 2.0 mode with MJPEG video format only

	Deactivate when not showing
Resolution/FPS Type	Custom
Resolution	1920x1080
FPS	
Video Format	Any Contraction of the second s
YI IV Color Space	млео
YUV Color Range	Partial
Buffering	Auto-Detect
教授教授教育	Flip Vertically

• USB 3.1 mode with RAW (YUY2) and MJPEG video formats

	Deactivate when not showing
Resolution/FPS Type	Custom
Resolution	1920×1080
FPS	60
Video Format	YUY2
¥ J¥ Color Space	Any YUY2
Y Cobr Pange	MJPEG
Buffering	Auto-Detect
	Flip Vertically

If you find that the captured media only has MJPEG format, simply flip the USB-C to USB-C cable connector connected to the CAMLIVE PRO 4K.

This Page Intentionally Left Blank

Chapter 4 ATEN OnAir Lite App

ATEN OnAir Lite Application

ATEN OnAir Lite app acts as the central controller for CAMLIVE PRO 4K. The app's design is a control panel where you can monitor program results, edit scenes, setup video and audio settings, etc. Download the ATEN OnAir Lite app from the Microsoft and install it on your laptop and PC.

- Note: 1. The maximum operating hour for the ATEN OnAir Lite app is 4 hours.
 - 2. Please make sure to enable the GPS function before you begin to use the ATEN OnAir Lite app.

Supported Systems

The ATEN OnAir Lite app supports the following mobile operating systems:


Mobile Operating System

Windows 10 or above

Installing the ATEN OnAir Lite App

- 1. Install the ATEN OnAir Lite app on a Windows laptop or PC.
 - a) Go to Microsoft Store.
 - b) In the search box, type "CAMLIVE PRO 4K".
 - c) Click the ATEN OnAir Lite to download the app.
- 2. From your downloads file, double-click the downloaded package and click **Install**.
- 3. Follow the on-screen instructions.

When you open the ATEN OnAir Lite app, the screen below appears.



Page Components

Project Device Help		- 🗆 ×
Current Project 2 VIDEO		
		Transition Style
	0	
2	FTB Fade to Black	
Scene		Transition Period
Scene 1 2 2 3 Scene 2 2 5 Scene 3 2 0	Scene 4	»» >
	3 4	Effect
Scene 5 🗹 Scene 6 🗹 Ø Scene 7 🖄 🕲	Scene 8 🗹	LOGO

No.	Component	Description
1	Project / Device / Help	 Project: click to create new project, open, import, or export projects, see all projects, and rename current project. See <i>Project Settings</i>, page 24. Device: click to disconnect the device, see or upgrade firmware and software version. See <i>Device Settings</i>, page 24. Help: click to run the tutorial and to see firmware and software version. See <i>Help</i>, page 25.
2	System Information	Click to see or upgrade the current software version and its information, or disconnect with the device. See <i>System Information</i> , page 25.
3	Deck Selector	Tap to select the desired configuration deck. Three decks are available: Video Mixer, Audio Mixer, and Settings. Video Mixer: see <i>Video Mixer</i> , page 26. Audio Mixer: see <i>Audio Mixer</i> , page 33. Settings: see <i>Settings Panel</i> , page 36.
4	Deck Content	The content depends on the selected deck.

Project Settings

Click to modify your project name, create, open, import, or export a project, and see available projects.

Project Device Help						- 🗆 ×
8 New project					SETTINGS	ATEN
Open project All project	>					
Export project					CHROMA KEY	
Import project						
Rename current project						
Green Screen Input	1	2 3	4			
Color Range			67			
Threshold			90			
Softness	•		10			
				R: 10 G	i: 255 B: 0	Ø

Device Settings

Click to browse or upgrade the current software and firmware version, or disconnect with the device.

Project Device Help				- 🗆 🗙
Disconnect the Device Upgrade firmware	VIDEO			ATEN
Upgrade Software Progra				
4		0		^
2 Scene		FTB Fade to Black		•
1 2	2		Transition Period	
Scene 1 2 3 Scene 2 2 3	Scene 3 🗹 🔇	Scene 4 🖸	Effect	0
S Scene 5 🗹 Scene 6 🗹 🛛	Scene 7 🗹 🕄	Scene 8	LOGO	

<u>Help</u>

Click to run the tutorial and to see the firmware and software version.



System Information

Click to connect or disconnect with the device, and to see or upgrade the current software version and its information.

Project Device Help				- 🗆 🗙	
Current Project New Project1					
Program					
		Software Vers	ion		
Scene	ND CONTRACTOR	v1.0.06	54		
	Connect	Upgrade	Period		
Scene 1 2 3 Scene 2					
1 3					
2 4 Scene 5 🖄 🛈 Scene 6					

Video Mixer

The Video Mixer deck page allows you to adjust effect on your video, scene selection and editing, and transition control.

The components of the page is shown below:

Project Device Help				– 🗆 ×
Current Project Project Name	VIDEO			ATEN
Program 1 4 Scene	3	2 CT FTB Fade to Black	Transition Style 4	. ↑
5 1 2 0 Scene 1 2 Scene 2	3	4 Scene 4	Transition Period 6	
2 4 2 Scene 5 2 Scene 6	1 2 2 Scene 7 2 0	3 4 Scene 8 🖄	Effect 7	


No.	Component	Description
1	Program	The program scene, or the on-air video output of the system.
2	Enlarge	Click to view the video source in full screen mode.
3	Fade to Black	Click to fade to video source to black screen.
4	Transition Style	Selects a transition style for the current stream (PGM).
5	Scene Selector	8 scenes are shown here. Tap a scene to put the scene into the program scene.
6	Transition Period	Specifies a time to begin the transition after 1, 2, and 3 seconds.

No.	Component	Description							
7	Effect Control	Click							
		display connected to the HDMI program output port. See <i>LOGO Position</i> , page 37 for more details.							
		Click to enable the chroma key effect on the							
		HDMI display connected to the HDMI program output port. See <i>Chroma Key</i> , page 37 for more details.							
		Click to show a video broader around the							
_		selected scene to appear on the HDMI display connected to the HDMI program output port.							

Scene Editor

To edit a scene, follow the steps below.


- 1. Select a scene from the scene selector.
- 2. Tap the provide the selected scene on the Video Mixer page.



No.	Component	Description
1	Return Button	Clicks to return to the Video Mixer page
2	Scene Name	This region displays the scene name. Click to edit the scene name.
3	Reset Button	Clicks to reset the current scene.
4	HDMI Display(s) and Resize Tool	Displays the selected HDMI display(s) with resize / crop tool. To resize the HDMI display, see <i>Resize</i> , page 29.
5	Layout Selection	Clicks to select a preferred layout. You can also resize the dual-view.
6	Undo / Redo	 Click to undo changes. Click to redo changes.
7	HDMI Sources	Clicks to select an HDMI source for the selected display(s).
8	Crop Button	Clicks to crop the HDMI display, see <i>Crop</i> , page 30.
9	Overlay Button	Clicks to switch between main display and overlay display, see <i>Reset Scene Button</i> , page 32. You can also resize and crop the overlay scene.

Resize

To resize HDMI display(s), select a scene and select an HDMI display. A resize tool \bigcirc will be visible on the selected HDMI display(s) in the scene editor page. Click and hold to drag the resize tool \bigcirc to resize the display(s).



Crop

To crop HDMI display(s), select a scene and select an HDMI display. A crop tool will be visible on the selected HDMI display(s) in the scene editor page.

Project Device Help	- 🗆 X
SCENE 3 Scene 3	Reset Scene
11 April and the the the the the the the the the	
$ \begin{array}{c} \begin{array}{c} \begin{array}{c} \begin{array}{c} \begin{array}{c} \begin{array}{c} \begin{array}{c} \begin{array}{c}$	
MC TRUCH AND TRU	
$ \begin{array}{c} \begin{array}{c} \begin{array}{c} \begin{array}{c} \begin{array}{c} \begin{array}{c} \end{array} \\ \end{array} \\ \end{array} \\ \begin{array}{c} \begin{array}{c} \end{array} \\ \end{array} \\ \begin{array}{c} \end{array} \\ \end{array} \\ \begin{array}{c} \end{array} \\ \begin{array}{c} \end{array} \\ \end{array} \\ \end{array} \\ \begin{array}{c} \end{array} \\ \end{array} \\ \end{array} \\ \end{array} \\ \begin{array}{c} \end{array} \\ \end{array} \\ \end{array} \\ \end{array} \\ \end{array} \\ \end{array} \\ \begin{array}{c} \end{array} \\ \end{array} $	
MT - MT - MD - MN - MT	
HONAT	

To crop the display(s), follow the steps below.


1. Select an HDMI display, click the crop tool p and the screen below appears.

Project Device Help	- 🗆 ×
SCENE 3 Scene 3	Reset Scene
L, ~ KIN "IDA, ~ "INT ~ 4 L, KIN, "OILA, "VIL, ~ KIN, "INA ~ "INA ~ "I ~ K	
ADAT ADAT ADAT ADAT ADAT ADAT ADAT ADAT	
HOLE TOME AND TOME AND TOME AND TOME AND TOME AND TOME AND TOME	
T HONO HONO	
1 HOND HILL AND HILL AND HOND HALL AND HOND HALL AND HOND HALL AND	

- 2. Click and hold to drag the crop tool 🚺 to adjust the cropping area.
- 3. (Optional) Click on to enlarge the crop display to help you easily adjust the cropping area.
- 4. Click for to relocate the cropping area.
- 5. When completed, click **Done**.


Overlay Button

To view the overly display from a dual-view scene, tap from the Scene Editor page.



Reset Scene Button

To reset or undo any changes made to the selected scene, tap Reset Scene from the Scene Editor page. A warning message appears, click **OK**.



Audio Mixer

The components of the Audio Mixer deck page is shown below:

Project Device H						- 0 ×
Current Project Na		VIDEO		AUDIO	SETTINGS	
		_ Input			2 O	utput
HDMI 1	HDMI 2	HDMI 3	HDMI 4	LINE IN	PGM	LINE OUT
AFV 🔻	ON 🔻	AFV 🔻	MUTE 🔻	ON 🔻	ON 🔻	ON 🔻
	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		-4 -4 -12 -12 -12 -12 -12 -12 -12 -12 -12 -12			


No.	Component	Description			
1	Audio Level Control	Slides the volume slider to control the volume of each audio source.			

No.	Component	Description
2	Audio Control	Clicks to select and adjust audio control.
		HDMI1 / HDMI2 / HDMI 3 / HDMI4: Clicks to select an audio control for HDMI 1, HDMI 2, HDMI 3, and HDMI 4 between AFV, ON, and MUTE.
		ON Audio follow Video MUTE
		AFV (Audio-Follow-Video): Broadcasting the source's video and audio at the same time. ON: The audio is turned on (unmuted). MUTE: The audio is turned off (muted).
		LINE IN: Clicks to select an audio control for LINE IN between ON and MUTE, and audio type between stereo and mono.
		● ON ● MUTE Type
		ON: The audio is turned on (unmuted). MUTE: The audio is turned off (muted). Type: Select between stereo and mono audio type.
		PGM: Clicks to select an audio control for PGM between ON and MUTE, and adjust compressor settings
		ON MUTE Compressor Threshold -5 dB
		ON: The audio is turned on (unmuted). MUTE: The audio is turned off (muted). Compressor: Clicks to enable or disable the compressor function and drag the dial to adjust the threshold. The default setting is disabled.

No.	Component	Description
		LINE OUT: Clicks to select an audio control for LINE OUT between ON and MUTE, audio source, and adjust compressor settings.
		ON ON OTE OdB
		ON: The audio is turned on (unmuted). MUTE: The audio is turned off (muted). Audio Source: Selects and audio output options between PGM, LINE IN, HDMI-1, HDMI-2, HDMI-3, or HDMI-4. Compressor: Clicks to enable or disable the compressor function and drag the dial to adjust the threshold. The default setting is disabled.
3	L/R Balance Control	Clicks and hold to drag and control which side of the sound source is to be more emphasized.
4	PGM and LINE OUT Level Control	Slides the volume slider to control the volume of PGM and LINE OUT.

Settings Panel

The Settings deck page is shown below:



General

Project Devic	ce Help						– 🗆 ×
Curre Proje	ent Project ect Name					SETTINGS	ATEN
	GENERAL				СН	IROMA KEY	
Re			720P	1080P	4K	LOG	50
Fra	ame Rate	24 25	30	50	60	LIV	/E
LO	GO Position		•		8		
PII	P Video Border	\bullet	-•		2		
				റ Reset t	o default		

Component	Description
Resolution	Selects a resolution for the HDMI display.
Frame Rate	Selects a frame rate for the HDMI display.

Component	Description
LOGO Position	 Selects a logo position for the logo to be displayed on the HDMI-enabled display. Adjusts the logo position close or further to the corner that you selected from the above logo position.
PiP Video Border	 Selects a color for the video border to appear on the HDMI display connected to the HDMI program output port. Adjusts the thickness of the video border.
Reset to Default	Resets the CAMLIVE PRO 4K back to the factory settings. A warning message appears, click OK .
LOGO	 Clicks to select an image file for your logo. The maximum logo size is 352 x 352 pixels, the image size will be proportionally scaled down automatically to fit the logo screen. The supported image formats are PNG / BMP / JPG.

Chroma Key

Chroma key allows user to composite two HDMI sources based on a color range, it usually goes hand-in-hand with a green screen. Our ATEN OnAir Lite app removes the color screen background and fill in the area with the HDMI sources.



Project Device Help					- 🗆 ×
Current Project Project Name				SETTINGS	ATEN
	GENERAL			CHROMA KEY	
Green Screen Input	1 2 3	4			
Color Range		67			
Threshold 	•	90			
Softness 	•	10			
			R: 10 G	6: 255 B: 0	Ø

Component	Description
Green Screen Input	Selects a target input for the Chroma Key.
Color Range	Adjust the color range for the colored background.
Threshold	Adjust the threshold for the colored background.
Softness	Adjust the softness for the colored background.

Appendix

Safety Instructions

<u>General</u>

- This product is for indoor use only.
- Read all of these instructions. Save them for future reference.
- Follow all warnings and instructions marked on the device.
- Do not place the device on any unstable surface (cart, stand, table, etc.). If the device falls, serious damage will result.
- Do not use the device near water.
- Do not place the device near, or over, radiators or heat registers.
- The device cabinet is provided with slots and openings to allow for adequate ventilation. To ensure reliable operation, and to protect against overheating, these openings must never be blocked or covered.
- The device should never be placed on a soft surface (bed, sofa, rug, etc.) as this will block its ventilation openings. Likewise, the device should not be placed in a built in enclosure unless adequate ventilation has been provided.
- Never spill liquid of any kind on the device.
- Unplug the device from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- The device should be operated from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
- To prevent damage to your installation it is important that all devices are properly grounded.
- Do not allow anything to rest on the power cord or cables. Route the power cord and cables so that they cannot be stepped on or tripped over.
- Position system cables and power cables carefully; Be sure that nothing rests on any cables.
- Never push objects of any kind into or through cabinet slots. They may touch dangerous voltage points or short out parts resulting in a risk of fire or electrical shock.
- Do not attempt to service the device yourself. Refer all servicing to qualified service personnel.

- If the following conditions occur, unplug the device from the wall outlet and bring it to qualified service personnel for repair.
 - The power cord or plug has become damaged or frayed.
 - Liquid has been spilled into the device.
 - The device has been exposed to rain or water.
 - The device has been dropped, or the cabinet has been damaged.
 - The device exhibits a distinct change in performance, indicating a need for service.
 - The device does not operate normally when the operating instructions are followed.
- Only adjust those controls that are covered in the operating instructions. Improper adjustment of other controls may result in damage that will require extensive work by a qualified technician to repair.

Technical Support

International

- For online technical support including troubleshooting, documentation, and software updates: <u>http://support.aten.com</u>
- For telephone support, see *Telephone Support*, page iv:

North America

Email Support		support@aten-usa.com
Online Technical Support	Troubleshooting Documentation Software Updates	http://www.aten-usa.com/support
Telephone Support		1-888-999-ATEN ext 4988 1-949-428-1111

When you contact us, please have the following information ready beforehand:

- Product model number, serial number, and date of purchase
- Your computer configuration, including operating system, revision level, expansion cards, and software
- Any error messages displayed at the time the error occurred
- The sequence of operations that led up to the error
- Any other information you feel may be of help

Specifications

Function	CAMLIVE PRO 4K		
Connectors			
Video In	4 x HDMI Type-A Female (Black) (HDMI TMDS compatible and without the support of FRL/VRR/ALLM/eARC. Max. input video resolution up to 3840 x 2160p60 including stereo audio signals only)		
USB Port	3.2 Gen1 USB-C Male (Black) Note: USB Type-A to USB-C and USB-C to USB-C cables included in the package.		
Video Output	1 x HDMI Type-A Female (PGM Video, Black) 1 x HDMI Type-A Female (Loop-Thru Video, Black)		
Audio Inputs	1 x Unbalanced Audio via 6.35mm TRS Connector (Black)		
Audio Outputs	1x Unbalanced Audio via 6.35mm TRS Connector (Black)		
Video Resolution			
Video HDMI Input	720p50, 720p60, 1080p25, 1080p30, 1080p50, 1080p60, 40960 x 2160 25p/30p/60p, 3840 x 2160 25p/30p/60p, HDMI unencrypted		
PGM HDMI Video Output	720p: 1280 x 720 25p/30p/50p/60p 1080p: 1920 x 1080 24p/25p/30p/50p/60p 2160p: 3840 x 2160 24p/25p/30p/50p/60p HDMI unencrypted		
Uncompressed USB Video (UVC) Stream with Audio (UAC)	720p: 1280 x 720 25p/30p/50p/60p 1080p: 1920 x 1080 24p/25p/30p/50p/60p 2160p: 3840 x 2160 24p/25p/30p		
Audio Sampling	16-bit PCM Encoded Audio at 44.1KHz and 48KHz Sampling Rates		
Environmental			
Operating Temperature	0 - 40 °C		
Storage Temperature	-20 – 60 °C		

Function	CAMLIVE PRO 4K	
Humidity	0 - 80% RH, Non-Condensing	
Minimum Hardware	PC/Mac:	
Requirement	◆CPU: Intel [®] i3 Dual Core 2.8Ghz or above	
	◆RAM: 4GB or above	
	◆One USB-C Interface or USB Type-A Interface	
Control		
Contact In	RS-232 Connection via RJ45 Interface	
RS-232	Flow Control: RTS/CTS, XON/XOFF	
	FIFO: 64 bytes	
	Baud Rate: 50bps ~921.6Kbps	
	Stop Bit: 2 Stop Bits (9600 8N2) or 1 Stop Bit (1,1.5, 2)	
	Parity: no parity	
	Signal: TxD, RxD, RTS, CTS, DTR, DSR, GND	
USB	Support ATEN OnAir Lite App, App downloadable from Microsoft Store	
OS Support	Windows 10 or above with UVC/UAC V1.1 Support	
	Mac OS X 10.13 or later with UVC/UAC Support	
Physical Properties		
Housing	Metal	
Weight	1.03 kg (2.27 lb)	
Dimensions (L x W x H)	20.00 x 16.46 x 4.40 cm (7.87 x 6.48 x 1.73 in)	

ATEN Standard Warranty Policy

Limited Hardware Warranty

ATEN warrants its hardware in the country of purchase against flaws in materials and workmanship for a Warranty Period of two [2] years (warranty period may vary in certain regions/countries) commencing on the date of original purchase. This warranty period includes the LCD panel of ATEN LCD KVM switches. For UPS products, the device warranty is two [2] years but battery is one [1] year. Select products are warranted for an additional year (see A+Warranty for further details). Cables and accessories are not covered by the Standard Warranty.

What is covered by the Limited Hardware Warranty

ATEN will provide a repair service, without charge, during the Warranty Period. If a product is detective, ATEN will, at its discretion, have the option to (1) repair said product with new or repaired components, or (2) replace the entire product with an identical product or with a similar product which fulfills the same function as the defective product. Replaced products assume the warranty of the original product for the remaining period or a period of 90 days, whichever is longer. When the products or components are replaced, the replacing articles shall become customer property and the replaced articles shall become the property of ATEN.

To learn more about our warranty policies, please visit our website: http://www.aten.com/global/en/legal/policies/warranty-policy/

> © Copyright 2023 ATEN® International Co., Ltd. Released: 2023-12-25

ATEN and the ATEN logo are registered trademarks of ATEN International Co., Ltd. All rights reserved. All other brand names and trademarks are the registered property of their respective owners.