



DVI Computer Sharing Device

CS261 / CS261TK

User Manual



www.aten.com

EMC Information

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Warning: Operation of this equipment in a residential environment could cause radio interference.

Achtung: Der Gebrauch dieses Geräts in Wohnumgebung kann Funkstörungen verursachen.

KCC Statement

유선 제품용 / A 급 기기 (업무용 방송 통신 기기)
이 기기는 업무용 (A 급) 전자파적합기기로서 판매자 또는 사용자는 이
점을 주의하시기 바라며, 가정 외의 지역에서 사용하는 것을 목적으로
합니다.

RoHS

This product is RoHS compliant.



User Information

Online Registration

Be sure to register your product at our online support center:

International	http://eservice.aten.com
---------------	---

Telephone Support

For telephone support, call this number:

International	886-2-8692-6959
China	86-400-810-0-810
Japan	81-3-5615-5811
Korea	82-2-467-6789
North America	1-888-999-ATEN ext 4988 1-949-428-1111

User Notice

All information, documentation, and specifications contained in this manual are subject to change without prior notification by the manufacturer. The manufacturer makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties as to merchantability or fitness for any particular purpose. Any of the manufacturer's software described in this manual is sold or licensed 'as is'. Should the programs prove defective following their purchase, the buyer (and not the manufacturer, its distributor, or its dealer), assumes the entire cost of all necessary servicing, repair and any incidental or consequential damages resulting from any defect in the software.

The manufacturer of this system is not responsible for any radio and/or TV interference caused by unauthorized modifications to this device. It is the responsibility of the user to correct such interference.

The manufacturer is not responsible for any damage incurred in the operation of this system if the correct operational voltage setting was not selected prior to operation. PLEASE VERIFY THAT THE VOLTAGE SETTING IS CORRECT BEFORE USE.

Package Contents

1 CS261 / CS261TK 2-Port DVI Computer Sharing Device

1 custom KVM cable set (1.8m)

1 power adapter

1 user instructions*

-
- Note:** 1. * Features may have been added to the KVM over IP console station since the user instructions were created. Please visit our website to download the most up-to-date version of the user manual.
2. Make sure that all of the components are present and in good order. If anything is missing or was damaged in shipping, contact your dealer.
 3. Read this manual thoroughly and follow the installation and operation procedures carefully to prevent any damage to the unit, and/or any of the devices connected to it.
-

Contents

EMC Information	ii
RoHS	ii
User Information	iii
Online Registration	iii
Telephone Support	iii
User Notice	iii
Package Contents	iv
About this Manual	vii
Conventions	viii
Product Information	viii
 1. Introduction	
Overview	1
Features	2
Requirements	4
Console	4
Computer	4
Cables	4
KVM Cables	4
Video Interface Converters	4
Operating Systems	5
Components	6
CS261 / CS261TK Front Panel	6
CS261 / CS261TK Rear Panel	7
(Optional) 2XRT-0015G KVM over IP Access Control Box	8
 2. Hardware Setup	
Installation	9
Installation Diagram	10
 3. Basic Operation	
Overview	11
Pushbutton Console Mode Selection	11
Hotkey Console Mode Selection	11
2XRT-0015G KVM over IP Access Control Box	12
LED statuses	12
 4. Operation	
Overview	13
Auto Mode	13
Private Mode (Console 1)	14
Screen Saver	15
DIP Switch Settings Table	15

Manual Mode	16
Timeout	17
Multiple EDID Selection	17
Invoke Hotkey Settings Mode	18
Hotkey Settings Mode Summary Table	19
Keyboard Emulation	21

5. The Firmware Upgrade Utility

Introduction	23
Downloading the Firmware Upgrade Package	23
Preparation	24
Starting the Upgrade	25
Upgrade Succeeded	27
Upgrade Failed	27
Firmware Upgrade Recovery	28

6. Appendix

Safety Instructions	29
General	29
Technical Support	31
International	31
North America	31
Specifications	32
CS261 / CS261TK Factory Default Settings	33
Operation Modes	34
Troubleshooting	36
Limited Warranty	37

About this Manual

This User Manual is provided to help you get the most from your CS261 / CS261TK. It covers all aspects of installation, configuration and operation. An overview of the information found in the manual is provided below.

Chapter 1, Introduction, introduces you to the CS261 / CS261TK system. Its purpose, features and benefits are presented, and its front and back panel components are described.

Chapter 2, Hardware Setup, describes how to set up your installation. The necessary steps, from basic to advanced setups, are provided.

Chapter 3, Basic Operation, explains the fundamental concepts involved in operating the CS261 / CS261TK.

Chapter 4, Operation, explains the CS261 / CS261TK's operating and hotkey settings mode as well as the EDID selection feature.

Chapter 5, The Firmware Upgrade Utility, explains how to use this utility to upgrade the CS261 / CS261TK firmware to the latest available version.

An Appendix, provides specifications and other technical information regarding the CS261 / CS261TK.


Note:

- ♦ Read this manual thoroughly and follow the installation and operation procedures carefully to prevent any damage to the unit or any connected devices.
- ♦ ATEN regularly updates its product documentation for new features and fixes. For an up-to-date CS261 / CS261TK documentation, visit

<http://www.aten.com/global/en/>

Conventions

This manual uses the following conventions:

- `Monospaced` Indicates text that you should key in.
- [] Indicates keys you should press. For example, [Enter] means to press the **Enter** key. If keys need to be chorded, they appear together in the same bracket with a plus sign between them: [Ctrl+Alt].
1. Numbered lists represent procedures with sequential steps.
- ♦ Bullet lists provide information, but do not involve sequential steps.
- > Indicates selecting the option (on a menu or dialog box, for example), that comes next. For example, Start > Run means to open the *Start* menu, and then select *Run*.
-  Indicates critical information.

Product Information

For information about all ATEN products and how they can help you connect without limits, visit ATEN on the Web or contact an ATEN Authorized Reseller. Visit ATEN on the Web for a list of locations and telephone numbers:

International	http://www.aten.com
North America	http://www.aten-usa.com

Chapter 1

Introduction

Overview

The CS261 / CS261TK is a DVI micro-processor controlled computer sharing solution that offers a multi-user/single-tasking experience and enables two users to share the use of a single USB computer from two separate consoles (monitor, USB keyboard, USB mouse, speaker and microphone). The CS261 / CS261TK is ideal for small office environments. All programs, files and resources on any connected computer can be easily accessed and shared by both users without the additional complexity and expense of setting up a network environment. Users are able to operate computers on the installation one by one while, for additional security, the other console's video and audio output is optionally disabled. The CS261 / CS261TK even provides a convenient OSD (On Screen Display) function that allows either of the Consoles to access any computer connected to the system by means of an on screen, console status driven interface.

Setup is fast and easy; plugging cables into their appropriate ports is all that is entailed. There is no software to configure, so there is no need to get involved in complex software installation routines or be concerned with incompatibility problems. Because the CS261 / CS261TK intercepts keyboard input directly, it works on any hardware platform and with all operating systems.

Responding to the growing use of audio input/output in the workstation space, the CS261 / CS261TK has been designed with built in microphone and speaker support, as well.

CS261TK is designed to work with an optional KVM over IP Access Control Box. The 2XRT-0015G KVM over IP Access Control Box allows users to enable or disable remote over IP control privilege by simply pressing a control button.

It's fast and easy to set up the 2XRT-0015G. Simply plug the 2XRT-0015G's cables to the CS261TK. There is no need to install software or configure devices - just plug and play,.

In addition, the cable length of the 2XRT-0015G reaches 5 meters, enabling connection to the transmitter over longer distances for more flexible installation.

Features

- ♦ The CS261 / CS261TK is a DVI computer sharing device that expands your control so that two users can easily share one computer using one of 2 modes: auto and manual
 - ♦ Auto: Computer access switches to a console on a first come first serve basis
 - ♦ Manual: Computer access switches to a console using the front panel pushbutton or a hotkey
- ♦ Supports Access Control Box which allows users to prohibit Console 2 from controlling (operating) (CS261TK only)
- ♦ Superior video quality - supports resolutions up to 1080p, 1920 x 1200 and 4K@30Hz¹
- ♦ Supports 2.1 channel stereo sound and high definition audio²
- ♦ HDCP compliant - supports HDCP-enabled devices
- ♦ EDID Expert™ - selects optimum EDID settings for smooth power up, high quality display and use of the best resolution across different monitors
- ♦ Supports RS232 serial commands - for switching operation and system configuration
- ♦ Console selection via the pushbutton, hotkey and RS232 commands - easily access the computer using any of these options
- ♦ Screen saver feature - blocks the console's display after a period of inactivity
- ♦ Mac/Sun keyboard support and emulation - users can use PC keyboards with consoles and still work on Macintosh/Sun platforms³
- ♦ Multilingual keyboard mapping - supports English, Japanese, French and German keyboards
- ♦ Multiplatform support - you can use the CS261 / CS261TK whether you are running a Windows, Linux, Mac or Sun system
- ♦ Upgradeable firmware through computer's USB port - stay current with the latest functionality improvements and updates with upgradeable firmware
- ♦ No software required - eliminate incompatibility and installation issues along with the need to configure software

-
- Note:** 1. 4K2K@30Hz is supported when using a DVI to HDMI cable.
2. High definition audio can be converted using a DVI to HDMI cable.
3. PC keyboard combinations emulate Mac/Sun keyboards.
-

Requirements

Console

- ♦ A DVI monitor capable of the highest resolution that you will be using on any computer in the installation
- ♦ A USB Keyboard and a USB Mouse
- ♦ Speakers and microphone (optional)

Computer

The following equipment must be installed on the computer that is to be connected to the system:

- ♦ A DVI video port
- ♦ USB Type A port
- ♦ Speaker and microphone ports (optional)

Cables

Use of substandard cables may damage the connected devices or degrade overall performance. For optimum signal integrity and to simplify the layout, we strongly recommend that you use the following high quality Custom Cable sets:

KVM Cables

- ♦ 2L-7D02U: 1.8m
- ♦ 2L-7D03U: 3.0m
- ♦ 2L-7D05U: 5.0m

Video Interface Converters

- ♦ 2A-127G: DVI to HDMI
- ♦ 2A-128G: HDMI to DVI


Operating Systems

Supported operating systems are shown in the table below:

OS		Version
Windows		2000 and higher
Linux	RedHat	6.0 and higher
	SuSE	8.2 and higher
UNIX	FreeBSD	3.51 and higher
	Sun	Solaris 8 and higher
Novell	Netware	5.0 and higher
Mac		OS 9 and higher

Components


CS261 / CS261TK Front Panel



No.	Component	Description
1	MANUAL/ AUTO selection pushbutton	This pushbutton is used to switch between Manual and Auto Modes. The default is Auto Mode. Repeatedly pressing the button cycles through the modes in the following order: Auto Mode -> Console 1 (Manual) -> Console 2 (Manual) -> Auto Mode.
2	C1 LED*	Lights when Console 1 accesses the computer. Turns off when Console 2 accesses the computer.
3	C2 LED*	Lights when Console 2 accesses the computer. Turns off when Console 1 accesses the computer.
4	MANUAL LED	Lights to indicate that the CS261 / CS261TK is set to Manual Mode. In Auto Mode the LED does not illuminate.


* In Auto Mode, when neither console is accessing the computer, both Console LEDs are illuminated.

CS261 / CS261TK Rear Panel



No.	Component	Description
1	serial port	Use an RJ-11 to RS232 cable to allow RS232 functions.
2	reset button	Press this reset button to reset the system.
3	power jack	The power adapter cable plugs in here.
4	DIP switch	This is a 4-pin DIP switch. Use it to enable/disable RS-232 commands, screen saver, private mode and privileged user settings.
5	PC port	The KVM cables that attach to your computers plug in here (see <i>Cables</i> , page 4, for a list of compatible KVM cables).
6	Console 1 ports	The cable from the DVI monitor, speakers, microphone, USB keyboard and mouse of Console 1 plugs in here.
7	Console 2 ports	The cable from the DVI monitor, speakers, microphone, USB keyboard and mouse of Console 2 plugs in here.

(Optional) 2XRT-0015G KVM over IP Access Control Box



No.	Component	Description	Indication
1	control button / LED	Press the button to enable or disable remote over IP control access.	Lights red
2	USB connector	Connects to a USB port to power on the device.	
3	PS/2 connector	Connects to the PS/2 port for control access.	
4	RJ-11 connector	Connects to the RJ-11 port for control access.	
5	RJ-232 connector	Connects to the RS-232 port for control access.	

Note: The 2XRT-0015G KVM over IP Access Control Box is an optional accessory designed for CS261TK only.

Chapter 2

Hardware Setup



1. Important safety information regarding the placement of this device is provided on page 29. Please review it before proceeding.
2. Make sure that power to all the devices you will be connecting up have been turned off. You must unplug the power cords of any computers that have the Keyboard Power On function.

Installation


1. Connect the DVI connector on the KVM cable to the Computer Port on the CS261 / CS261TK.
2. Connect the DVI connector on the KVM cable to the DVI video output port on the computer. Plug the USB connector into any available USB port.
3. Plug the keyboard, mouse and monitor for the console that you want to designate as Console 1 into the Console 1 port.
4. Repeat step 3 for Console 2.
5. Set the DIP switch (see *DIP Switch Settings Table*, page 15).
6. (Optional) Plug the RJ-11 connector of the 2XRT-0015G KVM over IP Access Control Box to the serialport on the rear side of the CS261TK.

Note: This step is for CS261TK only.

7. Plug the power adapter into the AC power source; plug the power adapter into the power jack on the CS261 / CS261TK.
8. Power on the computer and monitors.

Note: The mouse and keyboard connectors are USB 1.1 ports.

Installation Diagram



Chapter 3

Basic Operation

Overview

As a computer sharing device, the CS261 / CS261TK provides basic access via two different console modes: Console 1 Mode and Console 2 Mode. The CS261 / CS261TK provides three convenient methods of selecting console modes: Pushbutton Console Mode Selection – press the pushbutton on the front panel, Hotkey Console Mode Selection – enter combinations from the keyboard, and RS232 Serial Control – send RS232 commands.*

Note: Please refer to the CS261 / CS261TK RS232 Command User Manual for further details.

For CS261TK that is designed to work with the 2XRT-0015G KVM over IP Access Control Box. The 2XRT-0015G KVM over IP Access Control Box allows users to enable or disable remote over IP control privilege by simply pressing a control button.

Pushbutton Console Mode Selection

Press the pushbutton on the front panel repeatedly to bring the focus to the desired console mode as follows:

Auto Mode → Manual Mode (Console 1) → Manual Mode (Console 2) → Auto Mode.

The LED lights indicate that the console is accessing the computer.

Hotkey Console Mode Selection

Selecting console modes via hotkey works only within Manual Mode (Console 1 and Console 2 mode). Press the **[Scroll Lock]** key twice and then the **[Enter]** key to switch from Console 1 to Console 2.

Note: If using [Scroll Lock] conflicts with other programs, [Ctrl] can be used instead, e.g. [Ctrl] [Ctrl] [Enter].

2XRT-0015G KVM over IP Access Control Box

This optional 2XRT-0015G KVM over IP Access Control Box is a control button accessory to enable / disable remote KVM over IP access.

LED statuses

Button Status	LED	Function
Pressed	Red Light	Disable remote access
Released	Dim	Enable remote access

Chapter 4

Operation

Overview

The CS261 / CS261TK features two operation modes: Auto Mode and Manual Mode. For a brief overview of these modes, see *Operation Modes*, page 34.

Auto Mode

For general, low-priority scenarios, default Auto Mode offers the simplest usability for computer sharing where control of the computer is selected on a first come, first served basis.

Auto Mode operates according to the following rules:

1. When the CS261 / CS261TK is turned on it starts in Auto Mode, and operates on a first come, first served basis. Both Console LEDs are On; the Manual LED is Off.
2. The first user to strike the keyboard or move the mouse gains control of the computer. As soon as this occurs:
 - ♦ The Console LED that corresponds to the user's console turns On.
 - ♦ The Console LED for the other console turns Off.
 - ♦ The CS261 / CS261TK locks onto that user's console.
 - ♦ If the user uses the keyboard or moves the mouse, a message appears on the other user's monitor indicating that the system is in use. After 10 seconds, the message will disappear and the user can view the computer display again (if the other user stops using the keyboard and moving the mouse). When the other user uses the keyboard or moves the mouse again, the OSD message will reappear:

The System Is Occupied. Please Wait.
 - ♦ The user who has control of the computer can prevent the other user from viewing the computer display and listening to the audio output by entering the following Hotkey combination:

[Num Lock] + [-], [D]

If the other user uses the keyboard or moves the mouse, a message appears indicating that the system is in use. After 10 seconds, the message disappears and the monitor displays a black background. If the

user uses the keyboard or moves the mouse, the OSD message will reappear.

3. If the user who has access to the CS261 / CS261TK does not use the keyboard or move the mouse before the Timeout Period (set with hotkeys) elapses:
 - ♦ The CS261 / CS261TK unlocks from that user's console;
 - ♦ Then, the CS261 / CS261TK switches to Auto Mode;
 - ♦ Both Console LEDs turn On;
 - ♦ The Manual LED is Off (since the CS261 / CS261TK is in Auto Mode);
 - ♦ Either console may take control of the computer.
4. To terminate Auto Mode access, repeatedly press the MANUAL/AUTO Button until the desired console controls the device.

Private Mode (Console 1)

For high-priority scenarios, Private Mode offers the best control during computer sharing where a specific user can at any time take control of the system. Console 1 or Console 2 can be set as the privileged user by setting the DIP switch pin four on or off (see page 15), which can also prevent the non-privileged user from viewing and controlling the computer (see page 13). Private Mode operates within Auto Mode and does not include a Timeout Period.

To enter Private Mode:

1. Make sure that the device is in Auto Mode and that DIP switch pin 3 is set to the On position before powering on the CS261 / CS261TK.
2. Set Console 1 user as the privileged user if DIP switch pin 4 is set to On position. Otherwise, Console 2 user will be the privileged user.
3. Power on the CS261 / CS261TK.
4. Wait for the Timeout period to expire (default: 5s).
5. From the keyboard of the privileged user, press the Shift key six times within two seconds.

In Private Mode, the user who does not have control of the computer (i.e. not the privileged user) cannot view or hear the computer. As a result, the OSD warning message does not appear in Private Mode.

To exit Private Mode:

- ♦ From the keyboard of the privileged user, press the Shift key six times within 2 seconds.

Or

- ♦ Press the MANUAL/AUTO Button.

Screen Saver

To protect the screens, when the CS261 / CS261TK is in Auto Mode or Manual Mode and no one is accessing the computer, both monitors will display a black background. If one of the consoles accesses the computer, the black background screen will disappear. To enable this function, set DIP switch pin 2 to the On position.

DIP Switch Settings Table

DIP Switch Pins				Function
1	2	3	4	
On	X	X	X	RS232 Command Function Enabled
Off	X	X	X	RS232 Command Function Disabled
X	On	X	X	Screen Saver Enabled
X	Off	X	X	Screen Saver Disabled
X	X	On	On	Private Mode Enabled: Console 1 is the Privileged User
X	X	On	Off	Private Mode Enabled: Console 2 is the Privileged User
X	X	Off	On	Private Mode Disabled
X	X	Off	Off	Private Mode Disabled

Note: 1. Press a DIP switch pin down to turn it on and up to turn it off.

2. For best results, set the DIP switch pin before turning on both the CS261 / CS261TK or the computer.

Manual Mode

For longer tasks where uninterrupted access to the computer is required, Manual Mode offers the best operation setting for computer sharing. It is invoked by repeatedly pressing the MANUAL/AUTO Button to bring the focus to the desired console as follows:

Auto Mode → Manual Mode (Console 1) → Manual Mode (Console 2) → Auto Mode

- ◆ When Manual Mode is invoked, the CS261 / CS261TK switches to the selected console and prohibits the other console from controlling the computer. The selected console retains control until the MANUAL/AUTO Button is pressed again.
- ◆ A message appears on the other user's monitor indicating that the system is in use. After 10 seconds, the message disappears and the user can view the computer display. If the user strikes the keyboard or moves the mouse, the OSD message is displayed again:

The System Is Occupied. Please Wait.

- ◆ The user who has control of the computer can prevent the other user from viewing the computer display and listening the computer's audio output by entering the following Hotkey combination:

[Num Lock]+[-],[D]

If the other user strikes the keyboard or moves the mouse, a message appears indicating that the system is in use. After 10 seconds, the message disappears and the monitor displays a black background. If the user strikes the keyboard or moves the mouse, the OSD message is displayed again.

To switch access to the computer between the two consoles:

- ◆ Press the Manual/Auto Mode Button, or
- ◆ Enter the following hotkey combination:

[Scroll Lock], [Scroll Lock], [Enter]

Note: 1. This hotkey combination is for CS261 only.

2. If using the Scroll Lock key conflicts with other programs running on the computer, the Ctrl key can be used instead, e.g. [Ctrl][Ctrl][Enter]
-

Timeout

In Auto Mode, users can set timeout period by hotkeys. Please refer to the see *Hotkey Settings Mode Summary Table*, page 19, for hotkey parameters that correspond to Timeout lengths (see *Auto Mode*, page 13, for more information). The Timeout Period cannot be applied in Manual Mode and Private Mode.

Multiple EDID Selection

Users can select from Remix mode, Port1 mode and ATEN Default EDID mode, and from three resolutions. Multiple EDID selection can help improve video quality.

Users can select a desired EDID mode via Hotkeys (see *Hotkey Settings Mode Summary Table*, page 19, for more details).

Invoke Hotkey Settings Mode

To invoke HSM, please complete the following steps:

1. Press and hold down the Num Lock key.
2. Press and release the minus [-] key.
3. Release the Num Lock key.





-
- Note:** 1. The minus key must be released within half a second, otherwise the Hotkey invocation will be canceled.
2. There is an alternate key combination to invoke the HSM. Please see *Hotkey Settings Mode Summary Table*, page 19, for more details.
-

Hotkey Settings Mode Summary Table

Combination	Function
[Num Lock] + [-]	[H] Toggles between the default [Num Lock] [-] and alternate [Ctrl][F12] HSM invocation keys.
	[T] Toggles between the default [Scroll Lock] [Scroll Lock] and alternate [Ctrl][Ctrl] port switching keys.
	[B] Enables/Disables buzzer.
	[R] [Enter] Resets the hotkey settings to their default status.
	[D] Turn the other console's monitor and audio off or on. (This setting applies until changed or until CS261 / CS261TK is powered off.)
	[O] [N] [Enter] In Auto Mode, determines the amount of time that passes from the last input by the controlling console to when the console lock is released. N=1: 5 second timeout N=2: 60 second timeout N=3: 120 second timeout N=4: 255 second timeout
	[S] [N] [Enter] Determine the amount of time that passes from the last input by the controlling console to when screen saver appears. N=1: 1 minute N=2: 5 minutes N=3: 10 minutes N=4: 15 minutes N=5: 20 minutes
	[E] [N] [Enter] Set EDID mode. (N=1, 2, 3, 4, 5) N=1: Set Remix Mode. N=2: Set Port1 Mode. N=3: Set ATEN default EDID, 1280x720@60Hz N=4: Set ATEN default EDID, 1600x1200@60Hz N=5: Set ATEN default EDID, 1920x1080@60Hz
	[F1] Sets the PC keyboard layout.
	[F2] Enables Mac keyboard emulation.
	[F3] Enables Sun keyboard emulation.

Combination		Function
[Num Lock] + [-]	[F4]	Lists the current hotkey settings via the Paste function of a text editor. E.g. Hotkey: [num lock]+[-] and [scroll lock], [scroll lock] OS setting: PC Keyboard emulation: Enabled Mouse emulation: Enabled Keyboard layout: English
	[F5]	Performs a USB keyboard and mouse reset.
	[F6] [NN] [Enter]	Set the keyboard language layout. Where "NN" is two digital numbers that represents the keyboard language code: <ul style="list-style-type: none"> ◆ U.S. English: 33 ◆ Japanese: 15 ◆ French: 08 ◆ German: 09
	[u][p][g][r][a][d][e] [Enter]	Invokes the Firmware Upgrade Mode.
[Esc] or [Space Bar]		Exits Hotkey Settings Mode.

Keyboard Emulation

PC Keyboard	Mac Keyboard	PC Keyboard	Sun Keyboard
[Shift]	Shift	[Ctrl] [T]	Stop
[Ctrl]	Ctrl	[Ctrl] [F2]	Again
		[Ctrl] [F3]	Props
[Ctrl] [1]		[Ctrl] [F4]	Undo
[Ctrl] [2]		[Ctrl] [F5]	Front
[Ctrl] [3]		[Ctrl] [F6]	Copy
[Ctrl] [4]		[Ctrl] [F7]	Open
[Alt]	Alt	[Ctrl] [F8]	Paste
[Print Screen]	F13	[Ctrl] [F9]	Find
[Scroll Lock]	F14	[Ctrl] [F10]	Cut
	=	[Ctrl] [1]	 
[Enter]	Return	[Ctrl] [2]	 - 
[Backspace]	Delete	[Ctrl] [3]	 + 
[Insert]	Help	[Ctrl] [4]	
[Ctrl] 	F15	[Ctrl] [H]	Help
			Compose
			

Note: When using key combinations, press and release the first key (Ctrl), then press and release the activation key.

This Page Intentionally Left Blank

Chapter 5

The Firmware Upgrade Utility

Introduction

The purpose of the Windows-based Firmware Upgrade Utility is to provide an automated process for upgrading all CS261 / CS261TK switches in an installation. The program comes as part of a Firmware Upgrade Package that is specific for each device.

As new firmware versions become available, new firmware upgrade packages are posted on our website. Check the website regularly to find the latest information and packages.

Downloading the Firmware Upgrade Package

To download the firmware upgrade package:

1. that is not part of your KVM installation, go to our website (www.aten.com) and choose the model name of your device. A list of available firmware upgrade packages will appear.
2. Choose the firmware upgrade package that you wish to install (usually the most recent) and download it to your computer.

Preparation

To prepare for the firmware upgrade, do the following:

1. Use the *KVM Cable Set* provided with this unit to connect a USB port on your computer to the USB Type-B port from the *PC Port* section of your switch.
2. Shut down all the computers on the KVM installation.
3. The CS261 / CS261TK now enters Firmware Upgrade Mode. The two Ports LEDs flash together to indicate that the unit is in Firmware Upgrade Mode.


Note: While the CS261 / CS261TK is in Firmware Upgrade Mode, normal keyboard and mouse functions are suspended. You must complete the firmware upgrade or exit Firmware Upgrade Mode to regain normal control of the console.

Starting the Upgrade

To upgrade the firmware:


1. Run the downloaded firmware upgrade package file by double-clicking the file icon.

The *Firmware Upgrade Utility* welcome screen appears:



Note: The screens shown in this section are for reference only. The wording and layout of the actual screens put up by the Firmware Upgrade Utility may vary slightly from these examples.

2. Read and *Agree* to the License Agreement (enable the I Agree radio button).
3. Click **Next** to continue. The *Firmware Upgrade Utility* main screen appears. The devices capable of being upgraded are listed in the *Device List* panel:




4. Select your device. Its description appears in the Device Description panel. Click Next to perform the upgrade.

If you enabled Check Firmware Version, the Utility compares the device's firmware with that of the upgrade file's. If it finds that the device's firmware is newer than the upgrade or equal to it, it brings up the dialog box informing you of this and gives you the option to Continue or Cancel.


If you did not enable Check Firmware Version, the Utility installs the upgrade files without checking whether or not they are newer.

As the upgrade proceeds, status messages appear in the *Status Messages* panel, and the progress toward completion is shown on the *Progress* bar.



Upgrade Succeeded

After the upgrade has completed, a screen appears to inform you that the procedure was successful.



Click **Finish** to close the *Firmware Upgrade Utility*.

Set up your KVM installation again. See *Installation Diagram*, page 10.

Upgrade Failed

If the *Upgrade Succeeded* screen doesn't appear, it means that the upgrade failed to complete successfully. See the next section, *Firmware Upgrade Recovery*, for how to proceed.

Firmware Upgrade Recovery

There are three conditions that call for firmware upgrade recovery:

- ♦ When a firmware upgrade is manually aborted.
- ♦ When the mainboard firmware upgrade fails.
- ♦ When the I/O firmware upgrade fails.

To perform a firmware upgrade recovery, do the following:

1. Disconnect the USB connectors on the KVM cables from the computer.
2. Power on the CS261 / CS261TK. It will now work with the original firmware.

Safety Instructions

General

- ♦ Read all of these instructions. Save them for future reference.
- ♦ Follow all warnings and instructions marked on the device.
- ♦ Do not place the device on any unstable surface (cart, stand, etc.). If the device falls, serious damage will result.
- ♦ Do not use the device near water.
- ♦ Do not place the device near, or over, radiators or heat registers.
- ♦ The device cabinet is provided with slots and openings to allow for adequate ventilation. To ensure reliable operation, and to protect against overheating, these openings must never be blocked or covered.
- ♦ The device should never be placed on a soft surface (bed, sofa, rug, etc.) as this will block its ventilation openings. Likewise, the device should not be placed in a built in enclosure unless adequate ventilation has been provided.
- ♦ Never spill liquid of any kind on the device.
- ♦ Unplug the device from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- ♦ The device should be operated from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
- ♦ Do not allow anything to rest on the power cord or cables. Route the power cord and cables so that they cannot be stepped on or tripped over.
- ♦ Position system cables and power cables carefully; Be sure that nothing rests on any cables.
- ♦ When connecting or disconnecting power to hot-pluggable power supplies, observe the following guidelines:
 - ♦ Install the power supply before connecting the power cable to the power supply.
 - ♦ Unplug the power cable before removing the power supply.
 - ♦ If the system has multiple sources of power, disconnect power from the system by unplugging all power cables from the power supplies.

- ◆ Never push objects of any kind into or through cabinet slots. They may touch dangerous voltage points or short out parts resulting in a risk of fire or electrical shock.
- ◆ Do not attempt to service the device yourself. Refer all servicing to qualified service personnel.
- ◆ If the following conditions occur, unplug the device from the wall outlet and bring it to qualified service personnel for repair.
 - ◆ The power cord or plug has become damaged or frayed.
 - ◆ Liquid has been spilled into the device.
 - ◆ The device has been exposed to rain or water.
 - ◆ The device has been dropped, or the cabinet has been damaged.
 - ◆ The device exhibits a distinct change in performance, indicating a need for service.
 - ◆ The device does not operate normally when the operating instructions are followed.
- ◆ Only adjust those controls that are covered in the operating instructions. Improper adjustment of other controls may result in damage that will require extensive work by a qualified technician to repair.
- ◆ Do not connect the RJ-11 connector to a public telecommunication network.

Technical Support

International

Email Support	Email your questions and concerns to: support@aten.com
Online Support ♦ Technical Support ♦ Troubleshooting ♦ Documentation ♦ Software Updates	<ol style="list-style-type: none"> 1. Online technical support is available to Altusen customers through our e-Support Center: http://support.aten.com 2. Online troubleshooting that describes the most commonly encountered problems and offers possible solutions to them; online documentation (including electronically available manuals); and the latest drivers and firmware for your product are available at our website: http://www.aten.com
Telephone Support	886-2-8692-6959

North America

Email Support	Email your questions and concerns to: support@aten-usa.com
Online Support ♦ Technical Support ♦ Troubleshooting ♦ Documentation ♦ Software Updates	<ol style="list-style-type: none"> 1. Online technical support is available to Altusen customers through our e-Support Center: http://www.aten-usa.com/support 2. Online troubleshooting that describes the most commonly encountered problems and offers possible solutions to them; online documentation (including electronically available manuals); and the latest drivers and firmware for your product are available at our website: http://www.aten-usa.com
Telephone Support	1-888-999-ATEN

When you contact us, please have the following information ready beforehand:

- ♦ Product model number, serial number, and date of purchase.
- ♦ Your computer configuration, including operating system, revision level, expansion cards, and software.
- ♦ Any error messages displayed at the time the error occurred.
- ♦ The sequence of operations that led up to the error.
- ♦ Any other information you feel may be of help.

Specifications

Function			CS261
Computer Connections			1
Console Selection			Pushbutton, RS-232, Hotkey
Connectors	Console Ports	Keyboard	2 x USB Type A Female
		Mouse	2 x USB Type A Female
		Video	2 x DVI-D Female (White)
		Audio	2 x 3.5mm Audio Jack Female (Green - Speaker) 2 x 3.5mm Audio Jack Female (Pink - Mic)
	PC Port	Keyboard/ Mouse	1 x USB Type B Female
		Video	1 x DVI-D Female (White)
		Audio	1 x 3.5mm Audio Jack Female (Green - Speaker) 1 x 3.5mm Audio Jack Female (Pink - Mic)
	RS-232		1 x RJ-11 Female
	Power		1 x DC Jack (Black)
Switches	Mode Selection		1 x Pushbutton
	Reset		1 x Semi-recessed Pushbutton
	DIP		1 x 4 Pin
LEDs	Selected		2 (Green)
	Manual		1 (Orange)
Video			3840 x 2160 @ 30Hz
Power Consumption			DC 5V, 2.4W, 20BTU
Environment	Operating Temperature		0–50°C
	Storage Temperature		-20–60°C
	Humidity		0–80% RH, Non-condensing
Physical Properties	Housing		Metal
	Weight		0.72kg (1.59 lb)
	Dimensions (L x W x H)		21.00 x 8.80 x 5.55 cm (8.27 x 3.46 x 2.19 in.)

CS261 / CS261TK Factory Default Settings

Setting	Default
Mode Selection	Auto Mode
Mode Switching	[Scroll Lock] , [Scroll Lock]
Invoking HSM	[Num Lock] + [-]
Timeout	5 Seconds
Screen Saver	1 minute
EDID Mode	Remix Mode
Keyboard Operating Platform	PC Compatible
Keyboard Language Layout	English
Buzzer	Enabled
Firmware Upgrade Mode	Disabled

Note: Mode Switching with [Scroll Lock] , [Scroll Lock] is for CS261 only.

Operation Modes

The below table describes the CS261 / CS261TK's two operation modes and their setting options. Each setting's active and inactive users' statuses, as well as details on switching users, are also included.

Operation Mode	Setting	Active User	Inactive User	Switching
Auto Mode	Default	First come, first served	Using the keyboard or mouse triggers a message indicating the system is in use by the privileged user.	Wait for privileged user inactivity (default timeout: 5s).
	Private Mode	First come, first served unless preset console* activated**	Computer cannot be viewed and heard.	Preset console can gain exclusive control by pressing the Shift key six times within two seconds. Doing so again returns the installation to Default Auto Mode.
Manual Mode	C1 (Console 1) Mode	Console 1 has exclusive access to the computer***	Using Console 2's keyboard or mouse triggers a message indicating the system is in use by Console 1.	Press Scroll Lock twice to switch to C2 Mode.
	C2 (Console 2) Mode	Console 2 has exclusive access to the computer***	Using Console 1's keyboard or mouse triggers a message indicating the system is in use by Console 2.	Press Scroll Lock twice to switch to C1 Mode.

Note: 1. For more information on selecting a preset console, see *DIP Switch Settings Table*, page 15.

2. The preset console can be activated and gain exclusive control by pressing the Shift key six times within two seconds.

3. The user with control of the computer can disable display and sound to the other user by using the following hotkey combination: [Num Lock]+[-],[D]
 4. The press scroll lock twice to switch to C1 and C2 Mode operation is for CS261 only.
-

Troubleshooting

Symptom	Possible Cause	Action
Monitor does not display after the KVM cable set is hot-plugged.	DVI graphics card is not compatible with cable set hot-plugging.	Power off all devices on the installation; power off the CS261 / CS261TK; confirm all KVM cables are properly connected; power on the CS261 / CS261TK; power on the computers.
	Graphics card driver is not up-to-date.	Upgrade to the latest graphics card driver.
Mouse and/or keyboard is not responding.	Switch needs to be reset.	Power off all devices on the installation; power off the CS261 / CS261TK; wait five seconds; power on the CS261 / CS261TK again.
Cannot switch ports by pressing [Scroll Lock] twice.	Keyboard is incompatible with [Scroll Lock] invocation.	Switch to the alternate HSM invocation keys. See <i>Hotkey Settings Mode Summary Table</i> , page 19, for details.

Note: The symptom cannot switch ports by pressing [Scroll Lock] twice only applies to CS261 only.

Limited Warranty

ATEN warrants its hardware in the country of purchase against flaws in materials and workmanship for a Warranty Period of two [2] years (warranty period may vary in certain regions/countries) commencing on the date of original purchase. This warranty period includes the [LCD panel of ATEN LCD KVM switches](#). Select products are warranted for an additional year (see [A+ Warranty](#) for further details). Cables and accessories are not covered by the Standard Warranty.

What is covered by the Limited Hardware Warranty

ATEN will provide a repair service, without charge, during the Warranty Period. If a product is defective, ATEN will, at its discretion, have the option to (1) repair said product with new or repaired components, or (2) replace the entire product with an identical product or with a similar product which fulfills the same function as the defective product. Replaced products assume the warranty of the original product for the remaining period or a period of 90 days, whichever is longer. When the products or components are replaced, the replacing articles shall become customer property and the replaced articles shall become the property of ATEN.

To learn more about our warranty policies, please visit our website:
<http://www.aten.com/global/en/legal/policies/warranty-policy/>

MEMO

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

[illegible]

Manual Part No. PAPE-0370-AT1G



Released : 2021-03-03

© Copyright 2021 ATEN® International Co., Ltd.

ATEN and the ATEN logo are registered trademarks of ATEN International Co., Ltd. All rights reserved.
All other brand names and trademarks are the registered property of their respective owners.

ATEN International Co., Ltd., 3F, No. 125, Sec. 2, Datung Rd., Sijhih District, New Taipei City 221, Taiwan
Phone: 886-2-8692-6789 Fax: 886-2-8692-6767 TECHNICAL SUPPORT CENTER: 886-2-8692-6959